

DG16 FRAME - SHOULDER HARNESS ADJUSTMENT



1 Find the upper harness tensioner buckle and webbing.



2 Push on the buckle edge and pull on shoulder pad away from the frame to allow the webbing to release.



3 Find the lower harness stabilising webbing, there is a "buckle & barb" locking mechanism.



4 There are three points of adjustment, high medium and low, raising or lowering the harness.



5 Find your setting preference and pass the barb through the buckle to lock into the barb of choice.



6 Finally tighten the upper tensioner to a point where the mesh stands off from the main bag, this will add needed thoracic and lumbar support.

DG16 FRAME - LUMBAR PAD ADJUSTMENT



1 Reach behind the centre pad and feel for the velcro seam.



2 Pull and release the velcro to loosen the centre pad.



3 Fold open the centre pad and let it hang free from the frame.



4 Firmly with both hands rotate the lateral pads upwards 90 degrees.



5 Once at 90 degrees pull upwards away from the frame and allow the key to slide through the frame hole.



6 Our DG16 frame has three points of adjustment to allow for lumbar ride height.